



Product Cleaning Guide

Dortek GRP Doors and Frames

Dortek hygienic GRP doors and frames can be cleaned using any common cleaning agents and spirit based solvents.

The smooth gelcoat surface can withstand the strongest disinfectants, cleaning agents and other chemicals such as acetone, hydrogen peroxide, carbon tetrachloride and many others.

- When pressure washed, take care to prevent the penetration of water through the fixing screws and between the frame and wall construction.
- Do not use wire wool/steel wool or other abrasive cleaners.
- Rinse and dry surfaces as necessary.

Natural Anodised Aluminium

Natural anodised aluminium products such as frames, kick, push and design plates, mouldings and other accessories can be cleaned using any common cleaning agents and spirit based solvents.

- Do not use wire wool/steel wool or other abrasive cleaners.
- Rinse and dry surfaces as necessary.





Product Cleaning Guide

Powder Coated Aluminium

Powder coated aluminium products such as frames, kick, push and design plates, mouldings and other accessories can be cleaned using any common cleaning agents and spirit based solvents.

- Do not use acetone or other spirit based solvents, hydrogen peroxide, carbon tetrachloride, strong chlorine solvents or strong alkaline cleaning agents.
- Do not use wire wool/steel wool or other abrasive cleaners.

Stainless Steel

Stainless steel products such as frames, kick, push and design plates, mouldings and other stainless steel accessories can be cleaned using any common cleaning agents.

Acetone and other spirit based solvents can also be used and cleaners specifically for stainless steel products.

- Do not use saline, bleach or wire wool.
- Rinse and dry surfaces as necessary.